

Enable PMLN7851 Bluetooth earpiece on TLK110

1 Choose WAVE Devices in the WAVE Admin menu and select the device you want to modify. (Click on the TLK110 that you want to modify in the overview)

2 Select Actions.

3 Select Bluetooth Accessories

The screenshot shows the WAVE Admin interface. On the left sidebar, the 'WAVE Devices' menu item is circled in orange with a '1' next to it. On the right, an 'Actions' menu is open, with 'Bluetooth Accessories' circled in orange with a '2' and '3' next to it. The main content area shows 'Device Info' for a TLK100i device.

	Reported	Desired
Device Type	TLK100i	-
IMEI	354124100009653	-
Serial Number	341AVJ0244	-
Cellular Status	Activated	-

ATTENTION: If Bluetooth is not enabled, you must do this first under Settings and Menu Visibility.

The screenshot shows the Motorola Solutions settings page for a TLK-100 device. The 'Bluetooth' setting is circled in orange with a checkmark. The settings are as follows:

Brightness Level	1	1
Device Mode	user	user
Maintenance Mode PW	-	
Voice Announcements	On	<input checked="" type="checkbox"/>
Location	On	<input checked="" type="checkbox"/>
WiFi	On	<input checked="" type="checkbox"/>
Cellular	On	<input checked="" type="checkbox"/>
Bluetooth	On	<input checked="" type="checkbox"/>
Scan	Off	<input type="checkbox"/>
Do Not Disturb	Off	<input type="checkbox"/>

← DATAMATIK DEMO		Device Info	
DATAMATIK TLK DEMO		Settings	
Users		Menu Visibility	
TalkGroups		Reported	Desired
WAVE Devices		Location <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Clone Devices		Alert Tones <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Voice Announcements <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Brightness Level <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Do Not Disturb <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		WiFi <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Cellular <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Bluetooth <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Scan <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
		Contacts <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

When this is done, you can add Bluetooth accessory:

Up in the right corner, now select Bluetooth Accessories (Step 3)

You need to enter the name **EP910W_XXXX** and pin code **0000**. (XXXX = last 4 digit of the Bluetooth address. Use PC or Mobile phone to see the Bluetooth address.)

Name	MAC Address	Pin Code	Delete	Unpair	Edit
Silentex 3.3.5.2MW	886b0fe5225e	0000	Delete	Unpair	Edit
OCW_EARPIECE_PTT	001b41b24c22	0000	Delete	Unpair	Edit

Save the settings and the earpiece can be connected.

The PMLN7851 shall be set into LTE WaveOnCloud mode (see PMLN7851 manual for information)

Put the PMLN7851 in Pairing mode by pressing the MFB button for 5 – 6 seconds.

Turn off your radio Bluetooth function and turn on again.

Wait until you hear “your headset is connected”.

Then all is set and PMLN7851 works, including the PTT on the microphone boom.